

**USER AND INSTALLATION
MANUAL**

BSDE300

1. Revisions

Manual version	Data	Firmware version	Note
1.0	21/12/2012	1000	First draft.
1.1	04/06/2013	1005	New implementations and commands. Updates.
1.2	03/01/2014	1013	Updates.
1.3	03/02/2014	1022	Updates.
1.4	29/09/2014		Absolute encoder connection diagram update.
1.5	07/06/2016	1030	Updates.
1.6	25/01/2017		Serial Communication Driver Guidance
1.7	03/05/2018		Updates.
1.8	18/02/2020		Updates.

2. Attention!



BSDE series drives work in high voltage.

Even after removing the power to the drive, the internal capacitive circuits remain in voltage for a short period of time.

For this reason it is absolutely necessary to wait at least two minutes before operating inside the drive.

In addition, the drive is equipped with an internal recovery resistance that works in high voltage with very high operating temperature.

Therefore, do not touch the recovery resistance for any reason even when the drive is disabled.

3. Warnings

-
- 1 Before installing and using the equipment, read the manual carefully.

 - 2 We decline all responsibility for any improper use of the equipment other than those prescribed in the manual.

 - 3 Commissioning and installation is allowed only to qualified personnel, who are responsible for compliance with the safety rules imposed by the current regulation.

 - 4 In the specific case of use, the safety rules valid for the prevention of accidents must be considered. Installation, wiring and opening of the equipment and drive must take place in the absence of voltage.

 - 5 Equipment and drives must be installed in a contact-proof housing with an IP protection degree according to the standards.

 - 6 Position the equipment so that maintenance is facilitated and there is no danger of interference with moving parts.

 - 7 Make sure that sufficient ventilation is always guaranteed to dispose of drive leaks.

 - 8 In the event of a fire in the vicinity of the equipment, do not use extinguishing media containing water.

 - 9 In any case, avoid the penetration of water or other fluids inside the equipment.

 - 10 Any operation inside the equipment must be done in the absence of voltage. Since capacitors are present, wait at least 10 minutes before accessing for operations inside.
-

4. Summary

1.	Revisions.....	2
2.	Attention!.....	3
3.	Warnings	4
4.	Summary	5
5.	Drive	8
	Dimensions	8
	Currents that can be supplied	8
	Connectors description	9
	X1 connector: feedback input from resolver.....	10
	X2 connector: Power connector.....	11
	* X3 connector: RJ45 connector for CanBus	12
	X4 connector: STANDARD USB connector.....	13
	X5 connector: Command connector.....	14
	X6 connector: Digital input/output connector	15
	X7 connector: Encoder input/output connector	16
	Resolver feedback configuration.....	16
	Configuration with absolute encoder feedback.....	16
	* Configuration with feedback from incremental encoder and hall sensors.....	17
	* Configuration with incremental encoder feedback.....	17
	X8 connector: AUX output and unlock	18
	X9 connector: auxiliary power input	19
	X10 connector: Drive power mode selector.....	20
6.	Connections.....	21
	X5 and X6 connection diagram for analog speed reference	21
	X5 and X6 connection diagram for analog speed reference and hardware torque limitation	22
	Resolver and power connections diagram	23
	Connection diagram with absolute Encoder SSI protocol	24


7.	Modification of the Pid Value	25
	Influence of proportional action (Kp parameter)	26
	Influence of integral action (parameter Ki or Ti)	26
	Influence of the derivative action (parameter Kd or Td).....	27
8.	Enabling Drive	28
9.	Torque limit.....	28
10.	Analog torque limit calibration	28
11.	Digital/analog reference	29
12.	Analog reference calibration.....	30
13.	Feedback from resolver.....	31
14.	Enabling ramps.....	31
15.	Drive parameters.....	32
16.	Parameters	40
	Configuration (parameter 12)	40
	Status (parameter 13)	42
	Input (parameter 14)	44
	Drive command (parameter 15).....	45
	Drive command outcome (parameter 16)	47
	Drive status (parameter 17)	48
	Setting the simulated encoder (parameter 36).....	48
	Digital output event configuration (parameters 47 and 48)	49
	Digital input event configuration (parameters 49 and 51).....	50
	Digital input level configuration (parameters 50 and 52)	50
	Alarms (parameters 3 and 4).....	51
17.	Drive keyboard	53
18.	Serial communication.....	55
19.	Procedure for motor timing	56

7

20.	Procedure for moving the motor using the ESDRIVE2 interface	57
21.	Note.....	58

5. Drive

Dimensions




Dimension	Size (in mm)
A	85.10
B	160.00
C	149.00
D	138.00
And	5.50

Currents that can be supplied

MODEL	POWER SUPPLY	RMS RATED CURRENT AT 40°C	MAXIMUM RMS CURRENT
BSDE300 / 2,5A	Single/threephase 100 – 220 Vac Auxiliary power supply 24Vdc	2,5A	5A
BSDE300 / 5A		5A	10A
BSDE300 / 7,5A		7,5A	15A
BSDE300 / 10A		10A	20A

Connectors description


Numbering from left to right and from top to bottom.




Connector	Description
X1	Resolver Feedback Input
X2	Power
X3	CanBus
X4	USB
X5	Commands
X6	IN / OUT
X7	Encoder input / output
X8	AUX output and unlocking
X9	Auxiliary power supply
X10	Drive power mode

Buttons	Description
P1	Edit and view parameters
P2	
P3	
P4	

X1 connector: feedback input from resolver




Pin	Description
1	Resolver shield link. (0V adjustment board)
2	Resolver output -REF
3	Resolver output +REF
4	Resolve output -COS
5	Resolve output +COS
6	Resolve output -SEN
7	Resolve output +SEN

X2 connector: Power connector

Pin	Description
1	Motor U phase output
2	Motor V phase output
3	Motor W phase output
4	+AT output / external recovery resistance
5	-AT output / external recovery resistance
6	Clamp for ground connection
7	Power supply Input R
8	Power supply Input S
9	Power supply input T


Note: The connection of the external recovery resistance is to be made in case the drive without internal resistance is required.

*** X3 connector: RJ45 connector for CanBus**




Pin	Description
1	CAN H signal connection
2	CAN L signal connection
3	Screen connection
4	Not connected
5	Not connected
6	Not connected
7	Screen connection
8	Not connected

*** = INACTIVE**

X4 connector: STANDARD USB connector


Connection between drive and PC for configuration and monitoring, use a standard USB A-B cable no longer than three meters in length.

X5 connector: Command connector



Pin	Description
1	Differential analog input +REF (0 to 10 Volts)
2	Differential analog input –REF (from 0 to 10 Volts)
3	0V adjustment board
4	ENABLE input (active for 0)
5	Analog input for torque limitation (values from 0 to 10V)
6	Output +10V max 100mA
7	Output -10V max 100mA
8	0V adjustment board
9	PTC signal input with GND
10	Relay contact DriveOk max 1A @ 24Vdc
11	Relay contact DriveOk max 1A @ 24Vdc

X6 connector: Digital input/output connector



Pin	Description
1	0V adjustment board
2	Programmable digital input 1 (see note 1)
3	Programmable digital input 2 (see note 1)
4	0V adjustment board
5	Output 1 digital programmable PNP open collector max 10mA (see footnote 2)
6	0V adjustment board
7	Programmable analog/digital output 2 with 0/+5V signal (see footnote 2)

Note 1: For events associated with digital inputs, see **Digital Input Event Configuration** and **Digital Input Level Configuration** (page 50).

Note 2: For events associated with digital outputs, see the chapter **Digital Output Event Configuration** (page 49).

X7 connector: Encoder input/output connector

Connector contacts can have different meanings depending on the configuration you set (see **Configuration Parameter**).

Resolver feedback configuration

Pin	Description
1	Simulated encoder output A+
2	Simulated encoder output B+
3	Simulated encoder output Z+
4, 5, 6	---
7	Output 5V max 150 mA
8	Output 0V
9	Simulated encoder output A-
10	Simulated encoder output B-
11	Simulated encoder output Z-
12, 13, 14	---
15	---

Configuration with absolute encoder feedback

Pin	Description
1	DATA input- for absolute encoder
2, 3	---
4	CLK- output for absolute encoder
5, 6	---
7	Output 5V max 150 mA
8	Output 0V
9	DATA+ input for absolute encoder
10, 11	---
12	CLK+ output for absolute encoder
13, 14, 15	---


*** Configuration with feedback from incremental encoder and hall sensors**

Pin	Description
1	Incremental encoder input A+
2	Incremental encoder input B+
3	Z+ incremental encoder input
4	Incremental encoder input with HALL U+ sensors
5	Incremental encoder input with HALL V+ sensors
6	Incremental encoder input with HALL W+ sensors
7	Output 5V max 150 mA
8	Output 0V
9	Incremental encoder input A+
10	Incremental encoder input B-
11	Incremental encoder input Z-
12	Incremental encoder input with HALL U- sensors
13	Incremental encoder input with HALL V- sensors
14	Incremental encoder input with HALL W- sensors
15	5V direction signal output

*** Configuration with incremental encoder feedback**


Pin	Description
1	Incremental encoder input A+
2	Incremental encoder input B+
3	Z+ incremental encoder input
4, 5, 6	---
7	Output 5V max 150 mA
8	Output 0V
9	Incremental encoder input A+
10	Incremental encoder input B-
11	Incremental encoder input Z-
12, 13, 14	
15	5V direction signal output

*** = INACTIVE**

X8 connector: AUX output and unlock


Pin	Description
1	Drive Emergency Unlock Input (see Note)
2	Drive Emergency Unlock Input (see Note)
3	Output 0V
4	Output +24V max 150mA

Note: When absent, the emergency release is used to remove power to the power module. The absence of the connection between pins 1 and 2 is reported in the alarm section of the drive.

X9 connector: auxiliary power input

Pin	Description
1	Input 0V
2	Input +24Vdc

X10 connector: Drive power mode selector



Pin	Description
1	To select the 24Vdc auxiliary power supply connect pins 1 and 2 together
2	


or

3	To select the power supply from the 220Vac mains connect pins 3 and 4 together
4	


WARNING: It is important to select only one of the available options. Otherwise the drive will be damaged.

6. Connections


X5 and X6 connection diagram for analog speed reference



X5 and X6 connection diagram for analog speed reference and hardware torque limitation




Resolver and power connections diagram



Attention: for the connection of the resolver and motor cables it is recommended to use shielded cables. If the connection is provided with cables longer than 10 meters, please contact ES TECHNOLOGY support.

Connection diagram with absolute Encoder SSI protocol



7. Modification of the Pid Value

The adjustment pids are divided according to the mode of operation:


Way	Pid position	Pid speed	Pid current
Position Profiles	X	X	X
Position	X	X	X
Speed		X	X
Torque			X

The following table shows the position of the parameters.

Value	Parameter number
Pid Kp speed	53
Pid Ki speed	54
Pid Kd speed	55
Pid Kp position	56
Pid Ki position	57
Pid Kd position	58
Pid Kp current	59
Pid Ki current	60
Pid Kd current	61
Pid Id reference	62


Influence of proportional action (K_p parameter)

Proportional action allows you to influence both the speed and the response of the process. The higher the gain, the faster the response, the more the static error decreases (proportionally), and the more stability degrades. The best compromise between speed and stability must be found.




Influence of integral action (parameter K_i or T_i)

The integral action allows to cancel the static error between the measure and the setpoint. The higher the integral action (T_i small), the more the response accelerates and the more stability degrades. We also need to find a good compromise between speed and stability.



Influence of the derivative action (parameter K_d or T_d)

The derivative action is anticipatory. In fact, it adds a term that takes into account the rate of variation of the deviation, and this allows to anticipate in acceleration the response to the process, when the deviation grows, and in deceleration when the deviation decreases. The higher the derived action (large K_d), the faster the response accelerates. Again, the best compromise between speed and stability must be found.



8. Enabling Drive

Enabling the drive is possible in both hardware and software mode.

In hardware mode, enablement is a signal (active for 0) on the **X5 connector**.

In software mode, enabling is allowed by setting the appropriate flash in the status word or by writing the command in **parameter 15**.

9. Torque limit

The torque limit is a feature available in all modes of operation except the torque mode.

This limit can be both software and hardware (with a value ranging from 0 to 10 Volts) through the setting of the configuration word or by command and is expressed as a percentage of the maximum current parameter set (**parameter 7**).

To set the torque level in software mode you have to change the **parameter 38**.

10. Analog torque limit calibration

For a better use of the analog input of torque limitation it is necessary to calibrate the maximum and minimum value that the signal can reach to take advantage of the maximum possible range of values. Calibration values can be verified in parameters 79 (minimum value) and 80 (maximum value).

To carry out the calibration it is necessary

- Bring the analog input to the maximum possible value (however not exceeding 10 Volts)
- In the **Status** word, place the **Max Torque Limit Calibration** parameter on ON , or type **command 25** in **parameter 15**.
- Wait for the activated flag to automatically return to OFF or for parameter 16 to report the value 0.
- Once the calibration was deactivated, it was carried out.

The calibration for the minimum value is very similar:

- Bring the analog input to the lowest possible value
- In the **Status** word, place the **Min Torque Limit Calibration** parameter on ON , or type command **24** in **parameter 15**.
- Wait for the activated flag to automatically return to OFF or for parameter 16 to report the value 0.
- Once the calibration was deactivated, it was carried out.

To make the calibration values permanent, it is recommended to perform the parameter storage operation.

11. Digital/analog reference

By selecting the digital reference you have the possibility to set the maximum motor speed required by **parameter 30** in the case of operation of the drive in speed mode or the maximum torque by means of parameter 38 in the case of operation in torque mode.

In analog mode the voltage range to be applied to the connector terminals has an excursion from -10 to +10 Volts.

12. Analog reference calibration

For a better use of the analog input it is necessary to calibrate the maximum and minimum value that the signal can reach to take advantage of the maximum possible range of values. Calibration values can be verified in parameters 77 (minimum value) and 78 (maximum value).

To carry out the calibration it is necessary

- Bring the analog input to the maximum possible value (however not exceeding 10 Volts)
- In the **Status** word, place the **Max Analog Input Calibration** parameter on ON , or type **command 27 in parameter 15**.
- Wait for the activated flag to automatically return to OFF or for parameter 16 to report the value 0.
- Once the calibration was deactivated, it was carried out.

Similarly, for the calibration of the minimum value it is necessary:

- Bring the analog input to the minimum possible value (however not less than -10 Volts)
- In the **Status** word, place the **Min Analog Input Calibration** parameter on ON , or type command **26 in parameter 15**.
- Wait for the activated flag to automatically return to OFF or for parameter 16 to report the value 0.
- Once the calibration was deactivated, it was carried out.

For the adjustment of the zero-reference speed offset use the trimmer on the front

13. Feedback from resolver

Setting the feedback from resolver you need to set parameter 35 with the value 12.

14. Enabling ramps

To enable ramps it is necessary to bring the Ramp Enable flag to the ON status.

The values set in parameters 42 and 44 refer to the time it takes to bring the motor to the maximum speed set in parameter 30.

Parameters 43 and 45 refer to the time it takes to bring the motor from the maximum speed to 0.

15. Drive parameters

Number parameter	Description	Units of measurement	Range	Type of access
1 P001	Firmware version Drive firmware version			Reading
2 P002	Identifier Drive identifier		1 ÷ 32	Read / write
3 P003	Alarms Active alarm mask			Reading
4 P004	Alarm history Mask of historical alarms			Read/write
5 P005	Module current: maximum Maximum value of current supplied by module	A		Reading
6 P006	Module current: nominal Nominal value of current supplied by the module	A		Reading
7 P007	Set current: Maximum Maximum value of current supplied set by the user. The set current cannot be higher than the maximum current of the module (parameter 5)	A	5 ÷ 20	Read / write
8 P008	Set current: Nominal Nominal value of current supplied set by the user. The set current cannot be higher than the set maximum current	A	0,1 ÷ 10	Read / write
9 P009	Current: U phase Current U-phase reading	A		Reading
10 P010	Current: Phase V Current reading phase V	A		Reading
11 P011	Current: Phase W Current reading phase W	A		Reading
12 P012	Configuration Drive Configuration Mask			Read / write
13 P013	State Drive status mask			Read / write
14 P014	Input Drive Input Mask			Reading
15 P015	Drive: command Command given to the drive			Read / write
16 P016	Drive: Outcome Success of the command given to the drive			Reading

Number parameter	Description	Units of measurement	Range	Type of access
17 P017	Drive: Status Drive status: can take the value 0 (drive disabled) or 1 (drive enabled)			Reading
18 P018	Module temperature: value Value of the internal temperature of the module	°		Reading
19 P019	Bus voltage: value Bus voltage value	In		Reading
20 P020	Bus voltage: calibration Bus voltage calibration value	%	-100 ÷ +200	Read / write
21 P021	Bus voltage: maximum Maximum bus voltage value	In	100 ÷ 420	Read / write
22 P022	Bus voltage: maximum hysteresis Hysteresis value for maximum bus voltage	In	5 ÷ 20	Read / write
23 P023	Bus voltage: minimum Minimum bus voltage value	In	20 ÷ 250	Read / write
24 P024	Bus voltage: minimum hysteresis Hysteresis value for minimum bus voltage	In	5 ÷ 30	Read / write
25 P025	Bus voltage: brake connection Bus voltage value for braking activation	In	370 ÷ 420	Read / write
26 P026	Bus voltage: brake hysteresis Hysteresis value for brake activation voltage	In	10 ÷ 30	Read / write
27 P027	Braking: time Maximum braking actuation time	ms	1 ÷ 32767	Read / write
28 P028	I2t: alarm time Current limitation time delivered	ms	1 ÷ 32767	Read / write
29 P029	Motor speed: current Motor rotation speed value	Rpm	-8000 ÷ +8000	Reading
30 P030	Motor speed: maximum Value of the maximum speed set for the motor	Rpm	1 ÷ 8000	Read / write
31 P031	Resolver: polar pairs Number of polar pairs of the resolver	n.	1 ÷ 8	Read / write
32 P032	Motor: polar pairs Number of polar torques of the motor	n.	1 ÷ 8	Read / write

N.B. Parameters 21-22-23-24 cannot be changed with the keyboard

Number parameter	Description	Units of measurement	Value range	Type of access
33 P033	Motor: timing angle Motor timing angle	n.	0 ÷ 4096	Read / write
34 P034	Encoder Value read by encoder	n.		Reading
35 P035	Encoder: number of bits Sets the number of bits read by encoder (with resolver feedback set to 12)	n.	12 ÷ 32	Read / write
36 P036	Encoder: simulated Simulated encoder resolution	n.	0 ÷ 3	Read / write
37 P037	Analog reference Analog reference value	%	0 ÷ 100	Reading
38 P038	SW Torque Limit Reference Digital value of the torque limit	%	0 ÷ 100	Read / write
39 P039	Torque limit reference HW Analog value of the torque limit	%	0 ÷ 100	Reading
40 P040	Couple required Digital value of the required torque	%	0 ÷ 100	Read / write
41 P041	Motor speed: required Digital value of the required motor rotation speed. However, this limit is limited by the maximum motor speed parameter (parameter 26)	Rpm	-8000 ÷ +8000	Read / write
42 P042	CW acceleration ramp CW rotation acceleration ramp value	s	0,01 ÷ 30,00	Read / write
43 P043	CW deceleration ramp Value of the deceleration ramp with CW rotation	s	0,01 ÷ 30,00	Read / write
44 P044	CCW acceleration ramp CCW rotation acceleration ramp value	s	0,01 ÷ 30,00	Read / write
45 P045	CCW deceleration ramp Value of the deceleration ramp with CCW rotation	s	0,01 ÷ 30,00	Read / write
46 P046	Initial parameter Parameter number displayed	n.	1 ÷ 128	Read / write
47 P047	Exit Event Configuration 1 Event associated with exit 1	s	0 ÷ 32767	Read / write
48 P048	Exit Event Configuration 2 Event associated with exit 2	s	0 ÷ 32767	Read / write

Number parameter	Description	Units of measurement	Value range	Type of access
49 P049	Input Event Configuration 1 Configuring the event associated with input 1	n.	0 ÷ 32767	Read / write
50 P050	Input level 1 configuration Configuring Input Activation Level 1	n.	0 ÷ 1	Read / write
51 P051	Input Event Configuration 2 Configuring the event associated with input 2	n.	0 ÷ 32767	Read / write
52 P052	Input level 2 configuration Configuring Input Activation Level 2	n.	0 ÷ 1	Read / write
53 P053	Pid speed Kp Speed pid Kp setting	n.	0 ÷ 128	Read / write
54 P054	Pid speed Ki Ki setting of the speed pid	n.	0 ÷ 128	Read / write
55 P055	Pid speed Kd Kd setting of the speed pid	n.	0 ÷ 128	Read / write
56 P056	Pid position Kp Setting Kp of the position pid	n.	0 ÷ 128	Read / write
57 P057	Pid position Ki Ki setting of the position pid	n.	0 ÷ 128	Read / write
58 P058	Pid position Kd Setting Kd of the position pid	n.	0 ÷ 128	Read / write
59 P059	Pid current Kp Kp setting of the current pid	n.	0 ÷ 128	Read / write
60 P060	Pid current Ki Ki setting of the current pid	n.	0 ÷ 128	Read / write
61 P061	Pid current Kd Setting Kd of the current pid	n.	0 ÷ 128	Read / write
62 P062	Pid Reference Id Reference for flow current	n.	0 ÷ 128	Read / write
63 P063	Not used			
64 P064	Not used			

Number parameter	Description	Units of measurement	Value range	Type of access
65 P065	Canbus: node number Canbus Node Number	n.	0 ÷ 128	Read / write
66 P066	Canbus: length id Id length	n.	0 ÷ 1	Read / write
67 P067	Canbus: bus speed Bus speed	n.	0 ÷ 7	Read / write
68 P068	Canbus: Status Node status	n.	0 ÷ 65535	Read / write
69 P069	Canbus: Rx Errors Number of receive errors	n.	0 ÷ 32767	Reading
70 P070	Canbus: Tx Errors Number of transmission errors	n.	0 ÷ 32767	Reading
71 P071	Key repetition time Key repetition time	ms	10 ÷ 1000	Read / write
72 P072	Refreshment time parameters Initial parameter update delay	ms	1 ÷ 65535	Read / write
73 P073	Alarm list scroll time Scroll time of active alarms on the display	ms	1 ÷ 65535	Read / write
74 P074	Menu timeout Time to exit the menu in case of failure to press a button	s	1 ÷ 100	Read / write
75 P075	Not used	n.	0 ÷ 1	Read / write
76 P076	Not used	n.	0 ÷ 1	Read / write
77 P077	Refer. Analog: Minimum calibration Calibration of the analog reference against the minimum value	n.	0 ÷ 4096	Read / write
78 P078	Refer. Analog: Maximum calibration Calibration of the analog reference against the maximum value	n.	0 ÷ 4096	Read / write
79 P079	Ref. torque limit: calibr. minimum Calibration of the torque limit reference from the minimum value	n.	0 ÷ 4096	Read / write
80 P080	Ref. torque limit: calibr. maximum Calibration of the torque limit reference against the maximum value	n.	0 ÷ 4096	Read / write

Number parameter	Description	Units of measurement	Value range	Type of access
81 P081	Homing: speed Homing execution speed	Rpm	-8000 ÷ +8000	Read / write
82 P082	Homing: reduced speed Reduced homing execution speed	Rpm	-8000 ÷ +8000	Read / write
83 P083	Homing: zero altitude speed Zero altitude search speed	n.	0 ÷ 65535	Read / write
84 P084	Homing: zero altitude laps Number of revolutions at zero altitude	n.	-32767 ÷ +32767	Read / write
85 P085	Homing: zero altitude angle Angle at zero altitude	n.	0x00 ÷ 0xFFFF	Read / write
86 P086	Homing: position 0 laps Number of laps to be covered for position 0	n.	-32768 ÷ +32767	Read / write
87 P087	Homing: angle position 0 Angle to reach for position 0	n.	0x00 ÷ 0xFFFF	Read / write
88 P088	Positioner: sequence 1 - 4 Mask with the sequence of profiles to be executed	n.	0x00 ÷ 0xFFFF	Read / write
89 P089	Positioner: sequence 4 - 8 Mask with the sequence of profiles to be executed	n.	0x00 ÷ 0xFFFF	Read / write
90 P090	Posizionatore: consensus Mask with profile chaining type	n.	0x00 ÷ 0xFFFF	Read / write
91 P091	Number of revolutions Number of revolutions positioner	n.	-32768 ÷ +32767	Read / write
92 P092	Angle Current angle	n.	0x00 ÷ 0xFFFF	Reading
93 P093	Profile 1: Speed Profile execution speed 1	Rpm	0 ÷ +8000	Read / write
94 P094	Profile 1: Laps Number of revolutions for the execution of the profile 1	n.	-32768 ÷ +32767	Read / write
95 P095	Profile 1: Angle Motor stop angle profile 1	n.	0x00 ÷ 0xFFFF	Read / write
96 P096	Profile 1: Ramp Profile acceleration/deceleration ramp time 1	s	0,01 ÷ 30,00	Read / write

N.B. Parameters 81 through 128 cannot be changed with the keyboard

Number parameter	Description	Units of measurement	Value range	Type of access
97 P097	Profile 2: Speed Profile execution speed 2	Rpm	0 ÷ +8000	Read / write
98 P098	Profile 2: Laps Number of revolutions for the execution of the profile 2	n.	-32768 ÷ +32767	Read / write
99 P099	Profile 2: Angle Motor stop angle profile 2	n.	0x00 ÷ 0xFFFF	Read / write
100 P100	Profile 2: Ramp Profile acceleration/deceleration ramp time 2	s	0,01 ÷ 30,00	Read / write
101 P101	Profile 3: Speed Profile execution speed 3	Rpm	0 ÷ +8000	Read / write
102 P102	Profile 3: Laps Number of revolutions for the execution of the profile 3	n.	-32768 ÷ +32767	Read / write
103 P103	Profile 3: Angle Motor stop angle profile 3	n.	0x00 ÷ 0xFFFF	Read / write
104 P104	Profile 3: Ramp Profile acceleration/deceleration ramp time 3	s	0,01 ÷ 30	Read / write
105 P105	Profile 4: Speed Profile execution speed 4	Rpm	0 ÷ +8000	Read / write
106 P106	Profile 4: Laps Number of revolutions for the execution of the profile 4	n.	-32768 ÷ +32767	Read / write
107 P107	Profile 4: Angle Motor stop angle profile 4	n.	0x00 ÷ 0xFFFF	Read / write
108 P108	Profile 4: Ramp Profile acceleration/deceleration ramp time 4	s	0,01 ÷ 30,00	Read / write
109 P109	Profile 5: Speed Profile execution speed 5	Rpm	0 ÷ +8000	Read / write
110 P110	Profile 5: Laps Number of revolutions for the execution of the profile 5	n.	-32768 ÷ +32767	Read / write
111 P111	Profile 5: Angle Motor stop angle profile 5	n.	0x00 ÷ 0xFFFF	Read / write
112 P112	Profile 5: Ramp Profile acceleration/deceleration ramp time 5	s	0,01 ÷ 30,00	Read / write

Number parameter	Description	Units of measurement	Value range	Type of access
113 P113	Profile 6: Speed Profile execution speed 6	Rpm	0 ÷ +8000	Read / write
114 P114	Profile 6: Laps Number of revolutions for the execution of the profile 6	n.	-32768 ÷ +32767	Read / write
115 P115	Profile 6: Angle Motor stop angle profile 6	n.	0x00 ÷ 0xFFFF	Read / write
116 P116	Profile 6: Ramp Profile acceleration/deceleration ramp time 6	s	0,01 ÷ 30,00	Read / write
117 P114	Profile 7: Speed Profile execution speed 7	Rpm	0 ÷ +8000	Read / write
118 P118	Profile 7: Laps Number of revolutions for the execution of the profile 7	n.	-32768 ÷ +32767	Read / write
119 P119	Profile 7: Angle Motor stop angle profile 7	n.	0x00 ÷ 0xFFFF	Read / write
120 P120	Profile 7: Ramp Profile acceleration/deceleration ramp time 7	s	0,01 ÷ 30,00	Read / write
121 P121	Profile 8: Speed Profile execution speed 8	Rpm	0 ÷ +8000	Read / write
122 P122	Profile 8: Laps Number of revolutions for the execution of the profile 8	n.	-32768 ÷ +32767	Read / write
123 P123	Profile 8: Angle Motor stop angle profile 8	n.	0x00 ÷ 0xFFFF	Read / write
124 P124	Profile 8: Ramp Profile acceleration/deceleration ramp time 8	s	0,01 ÷ 30,00	Read / write
125 P125	Profile 9: Speed Profile execution speed 9	Rpm	0 ÷ +8000	Read / write
126 P126	Profile 9: Laps Number of revolutions for the execution of the profile 9	n.	-32768 ÷ +32767	Read / write
127 P127	Profile 9: Angle Motor stop angle profile 9	n.	0x00 ÷ 0xFFFF	Read / write
128 P128	Profile 9: Ramp Profile acceleration/deceleration ramp time 9	S	0,01 ÷ 30,00	Read / write

16. Parameters

Configuration (parameter 12)

What the configuration word bits mean	
Position Profiles Reference	How the drive works in position profile mode

Speed Reference	Operation of the drive in speed mode
Torque reference	Operation of the drive in torque mode
Analog/Digital Reference	Reference type: ON = digital OFF = analog
SW/HW torque limit	Type of torque limit: ON = software OFF = hardware
Enable SW/HW	Type of qualification: ON = software OFF = hardware
Tablet type Ptc/Ntc	Selection of the type of motor thermal pad
Motor timing	Performs motor timing
Parameter reading	Reads parameters from eeprom
Parameter storage	Stores parameters in eeprom
Parameter default	Place parameters with the default value
Incremental encoder	Select the incremental encoder as feedback
Hall + encoder	Select hall and incremental encoder sensors as feedback
Absolute encoder	Select the absolute encoder as feedback
Resolve	Select the resolver as the feedback.

The Position **Profile Reference**, **Speed Reference**, and **Torque Reference** fields are exclusionary mortgages. Selecting one automatically deselects the others.

The Analog/Digital Reference field allows you to select the type of reference sent to the drive. In analog reference mode, the speed or torque reference is given by the analog reference input of the drive (value visible in **parameter 37**). In digital mode, the reference values are obtained by setting **parameter 41** for the speed reference mode and **parameter 40** for the reference mode in pairs.

The torque limit (hardware or software) is obtained by setting **parameter 38** for the digital format or in hardware mode the value can be read in **parameter 39**.

By setting this value to 100% the drive is able to deliver all the current set in **parameter 7**.

The torque limit is always available except in **torque reference** mode.

The enablement type (selectable hardware or software) allows you to select the type of enablement required by the drive.

With the hardware enablement, the input of the drive intended for this task must be activated, while for the software enablement you can do either by setting the Sw **TorqueEnable** bit in the **Status** word or by means of a special command in **parameter 15**.

If the enable operation is successful, the **Enabled Drive** field in the Word **Input** is set to active.

The Ptc/Ntc Pad Type parameter allows you to choose the type of motor thermal pad.

The **Motor Timing** parameter allows the calculation of the timing angle of the motor. The procedure is started only with the drive disabled and with no alarm active. During execution, the motor takes a sprint to the set position. At the end of the procedure, the timing flag is reset and you can proceed in normal operations.

The Parameter **Read**, **Store Parameters** and **Default Parameters** parameters allow respectively the reading of parameters from eeprom, the writing of all parameters and the restoration of parameters according to factory values.

The **Incremental Encoder**, **Hall + Encoder**, **Absolute Encoder**, and **Resolver** parameters (all mutually exclusive) allow you to select the desired feedback type.

Status (parameter 13)

Meaning of state word bits		
SW torque enablement	Enabling drive:	ON = enablement request OFF = disabling request
Towards CW/CCW rotation	Set the rotation direction:	ON = CW OFF = CCW
Minimum torque limit calibration	Calibration of the minimum value of the analog input torque limit	
Max torque limit calibration	Calibration of the maximum value of the analog input torque limit	

Min analog input calibration	Calibration of the minimum value of the analog reference input	
Max analog input calibration	Calibration of the maximum value of the analog reference input	
Homing execution	Start running the homing process	
Encoder codifica Gray	Enable Gray encoding of the encoder value	
Encoder prot. SSI + ST	Enables the Encoder's SSI (Single Turn) protocol	

Enable Profile Execution	Start running profiles	
Enable Placement	Start positioning	

Enabling ramps	Enable ramps	

The **ENABLE SW Torque** parameter allows the drive to be enabled if there are no alarms and the software enablement of the drive has been previously selected.

The CW/CCW Rotation Direction parameter selects the direction of rotation of the motor.

Min torque limit calibration and **max torque limit calibration** allow you to calibrate, respectively, the minimum and maximum value of the analog torque limit input. The calibration of makes it necessary to have all the excursion of values from the analog. To perform this operation, the drive must be disabled and the analog input must be brought to the minimum value. Then you enable the flag. At the end of the reading the flag is automatically reset. Similarly, to calibrate the maximum reading, the value of the analog input must be brought to the maximum value and then the flag must be enabled.

Similarly, the **Min Analog Input Calibration** and **Max Analog Input Calibration** parameters allow analog input calibration.

Homing Execution allows the execution of the homing procedure set in the parameters.

Gray Encoding Encoder enables Gray encoding of the encoder to obtain a value in standard format.

Encoder prot. SSI selects the protocol type of the absolute encoder.

Enable Profile Execution enables the execution of placement profiles. To enable the flag it is necessary that the drive is set to work with reference to position profiles and enabled. As soon as the placement starts, the flag is reset.

Enable Placements allows you to start the placement process.

Enabling ramps allows the enabling of ramps during operation with speed reference. The ramp timing values can be set in parameters **42, 43, 44** and **45**.

In operation with reference to the position profiles, the ramps are always enabled.

All calibration procedures are not mandatory but are necessary to have the maximum excursion of the input values.

Input (parameter 14)

What word input bits mean		
Drive OK	The drive is ready to operate	
Drive enabled	Drive enablement status:	ON = enabled OFF = disabled
HW Enablement	Hardware Enablement Input Status:	ON = active input, enabling required OFF = inactive input, disabling request
Braking	Brake driving status:	ON = active braking resistance OFF = non-active braking resistance
Exit Event 1	Status of the event associated with Exit 1	ON = active output OFF = output disable
Exit Event 2	Status of the event associated with Exit 2	ON = active output OFF = output disable
Entrance Event 1	Status of the event associated with input 1:	ON = active input OFF = inactive input
Entrance Event 2	Status of the event associated with input 2:	ON = active input OFF = inactive input
Homing performed	Report that the homing procedure has been performed	
Key	Signal the press of one of the keys	

Hall 1	Hall 1 Sensor Status	
Hall 2	Hall 2 Sensor Status	
Hall 3	Hall 3 Sensor Status	
Positioner at height	Positioner Status:	ON = posizionatore in quota OFF = positioner not at height

Drive command (parameter 15)

The commands that can be given to the drive (via the parameter on the interface) are as follows:

Value	Way
0	Positioner profiles
1	Not used
2	Speed mode
3	Torque mode
4	Analog reference
5	Digital Reference
6	SW torque limit
7	Torque limit HW
8	SW Enable
9	HW Enable
10	Ptc motor pads
11	Ntc motor pads
12	Motor timing
13	Reading parameters from eeprom
14	Save parameters to eeprom
15	Set parameters with default values
16	Incremental encoder feedback
17	Feedback from Hall sensors and incremental encoder
18	Absolute encoder feedback
19	Resolver feedback
20	Enabling Drive (Software Enabled)
21	Disabling drive (software-enabled)
22	CW motor rotation
23	CCW motor rotation
24	Calibration of the minimum torque limit value
25	Calibration of the maximum torque limit value
26	Not used
27	Not used
28	Calibration of the minimum analog reference value
29	Calibration of the maximum analog reference value
30	Homing

with keypad, only values 1 through 23 are accepted

Value	Way
31	Enabling Gray encoder encoding
32	Disabling Gray encoder encoding
33	SSI encoder protocol selection
34	Enabling Profile Execution
35	Not used
36	Enabling ramps
37	Disabling ramps
38	Not used
39	Not used
40	Not used

Drive command outcome (parameter 16)

The command given through parameter 15 results in an outcome displayed in parameter 16.

For the results of the command, the following table applies:

Value	Description
0	No errors, successful
1	Operation not performed
2	Operation not performed, you need to disable the drive
3	Operation not performed, you need to enable the drive
4	Operation not performed, drive in alarm
5	Successful change
6	Wrong command
7	Operation not performed due to failure to select operating modes
8	Function not supported by the mode in use
9	Operation running

Drive status (parameter 17)

The parameter indicates the status of the drive:

Value	Outcome
0	Drive disabled
1	Drive enabled

Setting the simulated encoder (parameter 36)

In the case of feedback with resolver it is possible to have the simulated encoder output on the **X7 connector**.

Setting the parameter in the following table changes its resolution:

Value	Resolution (pulses per turn)
0	1024* Number of Polar Pairs Resolver
1	512 * Number of Polar Pairs Resolver
2	256* Number of Polar Pairs Resolver
3	128 * Number of Polar Pairs Resolver

Digital output event configuration (parameters 47 and 48)

The two outputs on the device can be associated with a series of events shown in the following table.

Any outputs driven are present on the **X6 Connector**.

Value	Event
0	No events
1	Drive Ok
2	Alarm
3	Brake connection
4	Drive ready
5	Drive operation in torque mode
6	Drive operation in speed mode
7	Drive operation in position mode
8	Drive enabled
9	Homing running
10	Homing performed
11	Drive at height
12	Fault power alarm
13	Module temperature alarm
14	Motor thermal pad alarm
15	Bus undervoltage alarm
16	Bus surge alarm
17	I2t alarm
18	Resolver alarm
19	Brake alarm
20	Disabling request alarm
21	Safety relay alarm
22	Encoder alarm
23	Current sensor alarm
24	Motor cable connection alarm
25	PWM speed (only available for output 2)
26	Current PWM (only available for output 2)

Digital input event configuration (parameters 49 and 51)

The two inputs can be associated with a series of events shown in the following table. The **parameters** to set the event associated with the inputs are the number **49** and **51** respectively.

Inputs are available on the **X6 Connector**.

Value	Event
0	No events
1	Micro of zero
2	Start positioning

Digital input level configuration (parameters 50 and 52)

You can configure the focus of digital inputs by setting parameter 50 for input 1 and 52 for input 2.

The possible values are as follows:

Value	Event
0	Active input for 0 Volts
1	Active input for 24 Volts

Alarms (parameters 3 and 4)

The following table describes the possible alarms reported by the drive

Alarms	
Fault power	Display on display: 
Description:	Indicates the general alarm status due to the intervention of the protection of the power section. In this case it is advisable to check the motor and the connections to it to check for any short circuits or insulation losses. An alarm of this type can also be caused by an incorrect calibration of the current ring.
Bus overvoltage	Display on display: 
Description:	BUS surge alarm. The signal can occur following a sudden braking of the motor that causes an increase in the BUS voltage beyond the threshold set as the maximum bus voltage or following an increase in the power supply network.
Sottotensione bus	Display on display: 
Description:	BUS undervoltage alarm. This alarm appears when the power supply is not present, check the status of the protective fuses on the power phases.
I2t	Display on display: 
Description:	Alarm when the set current threshold has been exceeded. This alarm is triggered when the drive delivers a current higher than the nominal for too long a period.
Disabling request	Display on display: 
Description:	The alarm indicates that the drive has been switched on with active hardware enablement or in the case of momentary intervention of an alarm. The report ceases when the hardware enablement request fails.
Resolve	Display on display: 
Description:	Resolver stop alarm. Check the integrity and correctness of connections with the resolver.

Motor thermal probe		Display on display: 
Description:	Motor overheating alarm. The drive is temporarily disabled as long as the anomaly persists and automatically restores itself as soon as the conditions of correct operation recur. In case of unjustified alarms, make sure that you have correctly set the type of thermal pad used by the motor.	
Module temperature		Display on display: 
Description:	The alarm signals that the internal temperature of the power module has reached its maximum value. The drive is automatically disabled. The signal is retracted when the lower temperature threshold is reached.	
Current sensor		Display on display: 
Description:	Signals the failure of one or more current sensors.	
Braking time or breakage		Display on display: 
Description:	The alarm is triggered when, following an intervention of the braking resistance, the bus voltage does not fall within the normal levels or after the maximum driving time of the resistance is reached.	
No security unlocking		Display on display: 
Description:	The alarm signals the absence of the release of the safety relay.	
Encoder		Display on display: 
Description:	Encoder stop alarm. Check the integrity of the encoder and the correctness of its connections.	

17. Drive keyboard

If you do not use the ESDRIVE2 interface for communication with the drive you can use the keyboard

On the front of the drive there are four buttons with which you can view and change the main operating parameters.

When switched on, the drive displays the firmware version for a few seconds.

When the drive is ready to operate on the display appears:

- The parameter value set in **parameter 46**
- The list of active alarms

During this state, pressing any of the keys allows access to the list of parameters.

The display appears as follows **P001**.

In this state the keys take on the following meaning:

P1 = previous parameter. In the case of the **P001** parameter the previous one will be the **P128**.

P2 = next parameters. In the case of the **P128** parameter, the next one will be **P001**.

P3 = displays or stores the parameter value

P4 = exit from the parameter list or confirm change of bit state (status column or historical reset alarms)

Once the desired parameter is selected, pressing the **P3** key displays the value of the parameter. This display can be in **decimal** or **hexadecimal** format depending on the type of parameter.

If the parameter is editable (i.e. it is not read-only) with the **P1** key it is possible to decrease its value, while with the **P2** key it is incremented. The values have an internal limit (both minimum and maximum).

If you want **to confirm the value of the parameter**, you need to press the **P3** button.

with the **p4** key the change is canceled the parameter will remain set to the previous value and you return to the parameter list

For parameters 4, 12 and 13 which are bit fields the procedure differs.

Once the parameter is selected with the **P3** key, the value **01-0/1** is displayed. The first value represents the first bit of the affected column (or the first alarm) while the second is the state. A value of **1** is associated with the focus and **0** is associated with the inactive state.

Once you have selected the bit to change, the **P3** key allows you to vary the state of the field (from **0** to **1** and vice versa). With the **P4** button you confirm the change of state and return to the parameter list

The drive keyboard allows you to view all the parameters but not to change them all

Parameter 15 Keyboard Command Drive goes up to a value of 23, no later than

Parameters 21-22-23-24 and 81 to 128 can only be changed using the ESDRIVE2 interface

18. Serial communication

The drive has the possibility to be connected via USB to a PC using a standard cable (see **connector X4**).

The characteristics of the serial channel are as follows:

Baud rate: **115200**

Stop bits: **1**

Data bits: **8**

Parity: **None**

Drive Selection: **BDSE300**

Protocol selection: **ES Technology**

N.B.=At the time of connection with the drive, the presence of an internet connection is required because the computer needs the FT232-FTDI UART serial driver.

For Windows 7, 8 and 10 operating systems the driver is automatically downloaded.

For older operating systems you may need to download the driver manually at <https://www.ftdichip.com/Drivers/VCP.htm>

19. Procedure for motor timing

For the timing of the drive with the motor the latter must be free, not charged, and the drive disabled

Using the ESDRIVE2 interface

- go to the first page of the parameters (F5)
- select parameter 31, enter the number of polar pairs of the resolver (value 1 by default) and press enter
- select parameter 32, enter the number of polar pairs of the motor (value 3 by default) and press enter
- go to the States page (F9)
- put the bit "timing" of the first column Configuration in "on" and click on "write" to perform operation
- the crankshaft moves until it finds the correct position and the timing bit returns to "off"
- enable the drive and check correct drive/motor operation
- disable the drive and save the new parameters in eeprom with a special icon or by putting in "on" the bit "stores parameters" of the Configuration column states page and click on "write" to perform operation

Using the keyboard

- press P1/P2 to select parameter 31 on the display, press P3 to enter and with P1/P2 choose the number of polar pairs of the resolver (value 1 by default), press P3 to save
- press P4 to return to the parameter list
- press P1/P2 to select parameter 32 on the display, press P3 to enter and with P1/P2 choose the number of polar pairs of the motor (value 3 by default), press P3 to save
- press P4 to return to the parameter list
- press P1/P2 to select parameter 15 on the display, press P3 to enter and with P1/P2 select the value 12 and press P3 to perform the timing
- the crankshaft rotates until the correct position is found
- enable the drive and check the correct functioning of the drive/motor system
- deactivate the drive
- press P1/P2 to select parameter 15 on the display, press P3 to enter and with P1/P2 select the value 14 and press P3 to store the parameters in eeprom

20. Procedure for moving the motor using the ESDRIVE2 interface

You can move the motor without having to connect unlocks or signals to the drive, after timing, using the ESDRIVE2 interface.

-power the drive, check that the drive is free of alarms and the display displays "diS" and connect with the ESDRIVE2

-open page STATES (F9)

-on the Configuration column put on the bit "Digital / analog reference" and click on the below "Write"

-on the Configuration column put on the bit "Enabling SW / HW" and click on the below "Write"

-to enable the drive go to the Status column and put on the bit "Enabling SW pair" and click on the below "Write"

-the display must go to the state " Abi. " and the motor remain stationary in pairs

-go to the second page of the parameters (F6) and write on parameter 41 "Motor speed required" the number of revolutions you want the motor to do and click send

-the motor must rotate at the set number of revolutions

-putting the negative sign before the number of revolutions the motor turns in the opposite direction

21. Note

The information contained in this document may be modified without notice by ES TECHNOLOGY s.r.l.

In the event of errors of any kind within this manual, please let us know to make the necessary changes, thus improving the service relationship of ES TECHNOLOGY towards its customers.



ES TECHNOLOGY S.R.L.

Via S. Bocconcello n° 13/15 - 36040 Meledo di Sarego (VI) - Italy

Phone +39 0444 821372 www.es-technology.com email: info@es-technology.com